

As far as general maintenance of the boiler we would recommend as follows;

- [1] Graphite grease or CV grease on combustion chamber door fibreglass rope once a month
 - [2] Vaseline or CV grease on handles once a month
 - [3] Clean both base of loading chamber and combustion chamber once a week of ash all the way to the back under the heat exchanger tubes
 - [4] Flue swept twice to three times a year including base of chimney fan (i hoover mine out).
 - [5] Check heat exchanger cleaning handle is moving freely (with about 90 degrees of play) otherwise they may need cleaning out (as per document attached)
- We have a special tool that you can buy if needs be to take out the turbulators if they are really stuck at £85 + vat including delivery as per the picture

All maintenance issues become much easier by continual use of nice dry wood 15% to 20% moisture content.